

## ***TLS Trailer Side Gate***

### ***Parts List to Keep Inside Lift Gate Power Unit Box***

1. P34186 Coil (White Wire) & Stem for running gate down
2. P34184 Coil for running gate In (Orange Wire)
3. P34183 Coil for running gate out (Red Wire)
4. P34186 Stem the Coils go over for In & Out
5. AT-501-354-040 Hose from cylinder to tee 72" wide gate
6. AT-501-354-035 Hose from cylinder to tee 60" wide gate
7. P38554 #50 SS Chain 95" Long
8. P38555 #50 SS Chain Connecting Link (2 per Chain)
9. P46748 16-5 Yellow Wire Cable 204" long
10. P46729 Lower Up & Down Switch
11. AA-551-538 Top Up & Down Switch
12. AA-551-537 In & Out Switch